

- 1) Cut two wire leads from the failed Panasonic lamp
- 2) Strip wires and crimp two terminal lugs on the end
- 3) Use proper screw and nut to attach leads to new Sony lamp



InternationalLight
TECHNOLOGIES

10 Technology Drive
Peabody, MA 01960
978-818-6180
978-818-6181 fax
www.intl-lighttech.com